Operating instructions

Commercial refrigerator



7081 513-00

GKv 1008

Disposal notes

- **Keep packaging materials away from children - polythene sheets and bags can cause suffocation!**
- Please return the packaging to an official collection point.

Your old appliance: This contains some reusable materials and should be disposed of properly - not simply with unsorted household refuse.

- Discarded appliances should be disabled: Remove the plug, cut through the connection cable and render the catch unusable so that children cannot become trapped inside.
- Ensure that the refrigerant circuit is not damaged when the appliance that is no longer needed is taken away for disposal.
- Details of the refrigerant can be found on the type plate.
- Appliances which are no longer needed must be disposed of in a professional and appropriate way, in accordance with the current local regulations and laws.

Range of appliance use

The appliance is suited only for cooling food. In the case of commercial food cooling, the pertinent statutory regulations have to be observed.

The appliance is not suited for storing and cooling pharmaceuticals, blood plasma, laboratory preparations or similar substances and products subject to the Medical Devices Directive 2007/47/EC.

Any misuse of the appliance may result in damage to or spoilage of the stored goods.

Furthermore, the appliance is unsuited for use in areas exposed to an explosion hazard.

Description of appliance and equipment



Safety instructions and warnings

- To prevent injury or damage to the unit, the appliance should be unpacked and set up by two people.
- In the event that the appliance is damaged on delivery, contact the supplier immediately before connecting to the mains.
- To guarantee safe operation, ensure that the appliance is set up and connected as described in these operating instructions.
- Disconnect the appliance from the mains if any fault occurs. Pull out the plug, switch off or remove the fuse.
- When disconnecting the appliance, pull on the plug, not on the cable.
- Any repairs and work on the appliance should only be carried out by the customer service department, as unauthorised work could prove highly dangerous for the user. The same applies to changing the mains power cable.
- Do not stand on the plinth, drawers or doors or use them to support anything else.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given initial supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Avoid prolonged skin contact with cold surfaces or chilled/frozen food. This could cause pain, numbness and frostbite. In the case of prolonged skin contact, protective measures should be taken, e.g. gloves should be worn.
- Do not consume food which has been stored for too long, as it could cause food poisoning.
- If you have a lockable appliance, do not keep the key near the appliance or within reach of children.
- Do not store explosives or sprays using combustible propellants such as butane, propane, pentane etc. in the appliance. Electrical components might cause leaking gas to ignite. You may identify such sprays by the printed contents or a flame symbol.
- Do not allow naked flames or ignition sources to enter the appliance. When transporting and cleaning the appliance ensure that the refrigerant circuit is not damaged. In the event of damage, make sure that there are no ignition sources nearby and keep the room well ventilated.
- Do not use electrical appliances inside the appliance.

Climate rating

The appliance is set to operate within specific ambient temperature limits according to its climate rating. These temperature limits should not be exceeded. The correct climate rating for your appliance is indicated on the type plate.

Climate rating	Ambient temperatures
SN	+ 10° to + 32 °C
N	+ 16° to + 32 °C
ST	+ 16° to + 38 °C
T	+ 16° to + 43 °C

Setting up

- Avoid positioning the appliance in direct sunlight or near cookers, radiators and similar sources of heat.
- The floor on which the appliance stands should be horizontal and level. Compensate for uneven floors with the adjustable feet.
- Standard EN 378 specifies that the room in which you install your appliance must have a volume of 1 m^3 per 8 g of R 600a refrigerant used in the appliance, so as to avoid the formation of inflammable gas/air mixtures in the room where the appliance is located in the event of a leak in the refrigerant circuit. The quantity of refrigerant used in your appliance is indicated on the type plate on the inside of the appliance.
- Do not connect the appliance to the supply with other equipment using an extension cable - risk of overheating.

Important!

You are recommended to clean the appliance before switching it on for the first time (see **Cleaning**).

Before switching the appliance on for the first time, plug the cleaning water drain opening in the floor of the appliance with the plug provided. This is important to ensure that the appliance works properly.



Cleaning water drain opening

A drain hose with an R 3/4 connection can be fitted to the underside of the appliance.
The water which collects in the interior during cleaning can be drained off in this way.



Connecting to the mains

Power supply (AC) and voltage at the operating point must comply with the details on the type plate, which is located on the inside left of the appliance. The socket must be fused with a 10 A fuse or higher, it must be away from the rear of the appliance and must be easily accessible.

Connect the appliance with a properly earthed fused plug and socket only.

The wires in the mains lead are coloured in accordance with the following code: green/yellow = earth, blue = neutral, brown = live.
Warning! This appliance must be earthed.

Dimensions

GKv 57
A= 1864 mm
B= 750 mm
C= 750 mm
D= 1447 mm
E= 790 mm

GKv 64
A= 2064 mm
B= 750 mm
C= 750 mm
D= 1447 mm
E= 790 mm



Operating and control elements



① Temperature display
② Temperature setting buttons
③ Audible warning on/off button
④ Child-proof lock display
⑤ On/off button
⑥ Fan switch

Switching the appliance on and off

To switch the appliance on: Press the **ON/OFF** button ⑤ until the temperature display lights up.

To switch the appliance off: Keep the **ON/OFF** button ⑤ pressed for approx. 3 seconds so that the temperature display goes out.

Setting the temperature

To reduce the temperature: Press the **DOWN** button.

To increase the temperature: Press the **UP** button.



- While you are entering the temperature, the set temperature will flash on the display.
- You can change the settings in increments of 1°C by briefly pressing the button again.
- The electronic control system will switch over automatically about 5 seconds after the button was last pressed, and the actual temperature will be displayed.

If **F1** appears in the display, the appliance has a fault. Consult your nearest customer service point.

Cooling

This appliance can be used for chilling all types of drinks and food.

The grid shelves can be moved to accommodate different height bottles or packages.

High-percentage alcohols should be tightly sealed and stored upright.

The ventilation slots on the inside must not be covered!



Cooling with fan

This generates relatively even temperatures on all of the shelves; all food will be chilled to the same temperature, which you can select.

It is generally recommended:
- in high room temperatures (approx. 30°C and higher),
- if the air humidity is high, e.g. during the summer.

To switch on:
Hold down the **Alarm** button and then press the **On/Off** button. The LED will come on.

To switch off:
Hold down the **Alarm** button and then press the **On/Off** button. The LED goes dark.



Audible warning signal

- This sounds when the door has been left open for longer than 180 seconds. The audible warning device is switched off by pressing the **Alarm** button.

- It sounds when the interior gets too warm or too cold. The temperature display will also flash.
  The audible warning device is switched off by pressing the **Alarm** button. The temperature display will continue to flash until the cause of the alarm has been rectified.

Additional functions

In set-up mode you can set the child-proof lock and adjust the brightness of the display.
The child-proof lock is designed to protect the appliance from being switched off and the temperature setting from being changed accidentally.

Activating set-up mode:
- Press the **Alarm** button for approx. 5 secs - the display shows **c** for child-proof lock. Note: The value to be altered flashes.
- Select the required function by pressing the Up/Down button: **c** = child-proof lock, **h** = display brightness.
- Now select/acknowledge the function by pressing the **Alarm** button briefly:

> For **c** = **child-proof lock**,
press the Up/Down button to select
c1 = child-proof lock **on** or
c0 = child-proof lock **off** and acknowledge with the **Alarm** button.
When the symbol is lit, the child-proof lock is activated.

> For **h** = **brightness**,
press the Up/Down button to select
h1 = minimum to
h5 = maximum brightness and acknowledge with the **Alarm** button.

Exiting set-up mode:
- Exit the set-up mode by pressing the On/Off button; after 2 min. the electronic system switches over automatically. The normal operating mode is activated again.

Safety lock

The lock is equipped with a safety mechanism.

Locking the appliance:
- Insert the key as shown by arrow **1**.
- Turn the key 90°.

To unlock the appliance, the same procedure must be repeated in the same order.



Defrosting

The appliance defrosts automatically. The water that forms on the rear wall drains into a reservoir at the back of the appliance and evaporates automatically through the compressor heat.

Cleaning

Before cleaning always switch off the appliance. Pull out the mains plug or remove/unscrew the fuse.

Clean the inside, equipment parts and outer walls with lukewarm water and a little detergent. Do not use abrasive or acid cleaners or chemical solvents.

Do not use steam cleaners because of the risk of injury and damage.

- Ensure that no cleaning water penetrates into the electrical components or ventilation grille.
- Dry all parts well with a cloth.
- The dust should be removed from the refrigeration unit and heat exchanger - metal grid at the back of the appliance - once a year.
- Do not damage or remove the type plate on the inside of the appliance. It is very important for servicing purposes.
- Use a commercially available stainless-steel cleaning agent for **stainless-steel appliances**.
- In order to achieve best possible protection, apply a stainless-steel care agent uniformly in grinding direction after cleaning. Points which are darker at the start and a more intensive coloration of the stainless-steel surface are normal.
- Do not use abrasive sponges or scourers, do not use concentrated cleaning agents and never use cleaning agents containing sand, chloride or acid or chemical solvents, as these would damage the surfaces and could cause corrosion.

Malfunctions

You may be able to rectify the following faults by checking the possible causes yourself:
- **Appliance does not function:**
– Is the appliance switched on?
– Is the plug correctly fitted in the mains socket?
– Is the socket fuse intact?
- **The temperature is not low enough:**
– Is the temperature setting correct (see "Setting the temperature")?
– Does the separately installed thermometer show the correct reading?
– Is the ventilation system working properly?
– Is the appliance set up too close to a heat source?

If none of the above causes apply and you cannot rectify the fault yourself, contact the nearest customer service department stating the type designation ❶, service number ❷ and appliance number ❸ as indicated on the type plate. The type plate is located on the inside left of the appliance.



Shutting your appliance down

If your appliance is to be shut down for any length of time, switch it off and disconnect the plug or remove the fuse. Clean the appliance and leave the door open in order to prevent unpleasant smells.

The appliance complies with the relevant safety regulations and EC directives 2004/108/EC and 2006/95/EC.

All types and models are subject to continuous improvement and the manufacturer therefore reserves the right to make modifications to the shape, equipment and technology.

Changing over door hinges

1. Remove screw from lower hinge bracket.



2. Lift door, tilt to the right and remove.



3. Turn lower hinge pin through 180° and remove.

4. Insert pin on the opposite side and turn through 180°.



5. Transfer upper hinge components to the opposite side.



6. Transfer lower hinge bracket and cover plate to the opposite side.



7. Locate door on upper pin.



8. Tilt door inwards from the left.

9. Secure hinge pin with screw.



10. Transfer handle and plugs to the opposite side of the door.